

How To Use

Twincur EB

FOR AUTOMATIC POLISHING MACHINES

- 1. Consult your operations manual for the proper setup procedures.
- 2. Choose the correct size diameter of Twincur EB for your machine specifications.
- 3. Setup the stone on your single-head edge polishing machine.
- 4. Use a metal bond shaping wheel to create the bullnose shape on the material. Do not attempt use Alpha® Twincur EB wheels to create the Bullnose edges as they are designed only for the polishing stages.

FOR SINGLE-HEAD (C-Frame Polishers)

- 1. Attach the first Twincur EB grit onto the spindle of the machine. Make sure the Hard Stop/Mechanical Stop is disengaged when using the Twincur EB wheels.
- 2. Adjust the movable Cross-Travel Flags so the edge of the material is about ½ way between the edge of the Twincur EB wheel and its center water hole.
- 3. Adjust the head pressure setting to the desired setting most suitable for the selected grit.
- 4. Set traverse speed.
- 5. Provide water and proceed with the polishing stages of Twincur EB.

FOR MULTIPLE-HEAD

- 1. Attach Twincur EB (5" or 6") wheels on your multi-head line polisher in the correct polishing sequence. (#200, #500, #1000, #2000 and #3000 grits)
- Center the heads with the material being polished. (See equipment manual for details).
- 3. Adjust the head pressure setting to the desired setting most suitable for the selected grit.
- 4. Adjust the belt speed to 1 foot per minute. (12 inches, 30.48cm or 304.8mm per minute)
- Provide appropriate water flow to each Twincur EB wheel.