

Helpful Hints

Cordless Saw Blade for Tile

- In order to maintain proper speed, always start with a fully charged battery.
- Do not force the blade to cut; allow the diamonds time to cut through the material. Slower cutting helps eliminate chipping on the cut edge.
- Take appropriate steps to assure personal safety when performing any cutting application
- Review operations manual of the power tool to assure proper usage.