

Helpful Hints

PVA QC Style

- PVA should be used to polish in one direction making sure the you remove all prior scratches before moving on to next grit.
- Shape the stone to the desired pattern using the Alpha® Profilers, Profile Wheels or Dry Grinding Wheels. On very soft marble you may use the PVA Extra Coarse (white) grit to help shape and blend.
- Use just a light touch and let the wheel glide along the stone. Pressing too hard will cause the PVA to heat up.
- PVA is a special cushioned material which prevents bouncing. If bouncing occurs, check to make sure that the backer pad is properly attached to the spindle and the PVA MS wheel is properly locked.
- Polishing to a high degree is accomplished very quickly. Always use the wheel at a slight angle (15 degrees) never flat.
- The product is simple to use; however, new users should practice on scrap materials to develop the skill.
- For wet polishing of Marble, Granite, Porcelain and Engineered Stone, try Alpha® Ceramica and Ceramica EX Diamond Discs. Alpha® Sandpaper can also polish Marble for wet/dry polishing applications.
- Always wear eye protection and proper personal safety equipment when using this product.