



SUGGESTED USAGE

NOT FOR POLISHING FLAT SURFACES OR SYNTHETIC STONES.

- 1. Cut workpiece to size.
- 2. Clamp workpiece securely to prevent vibration.
- Shape edges to desired pattern with Alpha[®] PVA Extra Coarse (WHITE), Alpha[®] Dry Diamond Grinding Wheels, or Alpha[®] Profile Wheels.
- For best results, carefully prepare the workpiece. PVA Finer Grit Wheels will not work properly over gauges, scratches and rough areas.
- 5. Starting with PVA Coarse (**RED**) lightly run the wheel over the marble. Do not push down, and don't use water.
- Continue polishing with Medium (BLUE), Fine (GREEN), and finally Extra-Fine (YELLOW).

Alpha Professional Tools[®] 103 Bauer Drive, Oakland, NJ 07436

800-648-7229 • Fax: 800-286-0114 www.alpha-tools.com Copyright © 2015 Alpha Professional Tools. All rights reserved.

MADE IN JAPAN