

How To Use

Vetro

Choose the proper power tool best suited for the application and diameter of the blade. Alpha® Vetro blades are WET USE only.

Use the Alpha® AWS-110 Wet Stone Cutter with the 4-3/8" Alpha® Vetro blade.

Make sure that the blade's directional arrows match the spindle rotation of your power tool.

Adjust the depth of your cut; generally, if the blade is 1/8" below the material you are cutting, this is sufficient.

Slowly push the blade into the material maintaining a consistent slow traverse speed until you cut through the entire piece of material. A slow consistent pushing motion will allow the diamonds, within the blade's cutting edge, to cut the material easily and minimize chipping on the edge.